

Impact of the detector definition on the Reverse Monte Carlo calculation result – FASTRAD[®] 3.7

P. Pourrouquet, V. Traisnel, and A. Varotsou (TRAD)
G. Rolland (CNES)

Most of TID calculations performed with point detectors

But

- **How to select their location?**
 - On the surface,
 - At the center,
 - Somewhere in between...

- **Is it possible to compare doses for point and volume detectors?**
 - Shapes to consider: cube, slab
 - Dimensions : 1, 10 or 100 μ m


- **Is there an impact of the environment?**
 - Protons,
 - Electrons (GEO and Jovian)

- **At component level**
 - ▶ Detector definition
 - ▶ Shielding geometry effect


- **For external materials**
 - ▶ Point detector locations
 - ▶ Volume detector dimensions and shapes

- **Conclusions**

Detector Definition




- **10 μ m Cube**



- **10 μ m Cube**

Zoom area




- **1 μ m Cube (area of a cube face = 1 millionth of the surface die area)**

- **100 μ m Slab**




- **10 μ m Slab**



- **10 μ m Slab**

Zoom area




- **1 μ m Slab (area of the slab surface = area of the die surface)**




Component – Point detector definition


- Point detector set at 50 μ m below the surface of the die



- Point detector set at 5 μ m below the surface of the die




- Point detector set at $0.5\mu\text{m}$ below the surface of the die





3D Radiation Models


- Simple models



TO 39






SO 14



FP 14

- Complete satellite model



Results for Components

Location/dimension impact for point and volume detectors

- **No effect for protons (discrepancies below 10%)**

- **Electrons : non negligible impact**
 - ➔ $\text{Dose}_{\text{Point}0.5} \sim \text{Dose}_{\text{Point}5} \geq \text{Dose}_{\text{Point}50}$ (max. 11%)

 - ➔ $\text{Dose}_{\text{Slab}1} \geq \text{Dose}_{\text{Slab}10} \geq \text{Dose}_{\text{Slab}100}$ (max. 25%)

 - ➔ $\text{Dose}_{\text{Cube}1} \geq \text{Dose}_{\text{Cube}10} \sim \text{Dose}_{\text{Cube}100}$ (max. 44%)

Impact of detector type




- **No effect for protons (discrepancies below 11%)**
- **Electrons : non negligible impact**

$$\text{Dose}_{\text{Point}} \geq \text{Dose}_{\text{Slab}} \geq \text{Dose}_{\text{Cube}}$$

Except for a GEO mission at surface: $\text{Dose}_{\text{Slab}} > \text{Dose}_{\text{Point}} > \text{Dose}_{\text{Cube}}$
(max. 27%)


Results for External Materials

- **Sampling on different materials located outside the satellite**
 - ▶ NBK7 for lenses
 - ▶ Zerodur and SiC for mirrors
- **Cylindrical models**
 - ▶ 5 cm radius and 2 cm thickness
 - ▶ Detectors set from 1 μ m to 1mm




Study on locations/dimensions for same detector type confirms the steep dose gradient for satellite external surfaces

Dose evolution according to the volume detector thickness and point detector location - GEO mission



Impact of detector type:

- **No effect between volume detectors except at surface with:**
 - $Dose_{Cube} < Dose_{Slab}$ (up to 27%)
- **High impact between volume and point detectors due to the steep gradient dose**
 - For example $Dose_{Point}(50\mu m \text{ depth}) < Dose_{Cube}(100\mu m \text{ thickness})$
Up to 300% difference for protons



Proton environment:

- **No effect of the detector type or location/dimension**

Electron environment:

- **Detector location/dimension:**
 - ▶ Gradient for volume detectors for GEO mission (Cube: max. 44% / Slab: max. 25%)
 - ▶ Lower gradient for point detectors (up to 13%)

$$\text{Dose}_{100\mu\text{m}} < \text{Dose}_{10\mu\text{m}} < \text{Dose}_{1\mu\text{m}}$$

- **Detector type:**
 - ▶ Generally observed effect

$$\text{Dose}_{\text{Cube}} < \text{Dose}_{\text{Slab}} \leq \text{Dose}_{\text{Point}}$$

Comparison on detector dimensions/locations:

- **Very steep gradient according to the point detector depth or the volume detector thickness**

Comparison on the detector types:

- **Difference between cubes and slabs only at surface**
- **Important difference between volume and point detectors**

It is important to adapt the choice of the detector to the sensitive effect to study (volume or at a certain location/depth)

Thank you for your attention